



Specs: 26.16Specs20

Repairing Cracks in Concrete.

Products required

- **MAXGRIP**
- **MAXJOINT ELASTIC**
- **MAXSEAL FLEX**

Method

1. All cracks should be cleaned out to remove any loose concrete. If it is a hairline crack then cut out to open up the crack. Minimum requirements = 15mm x 15mm.
2. Dampen void to be filled before applying **MAXGRIP**. OR
3. **MAXJOINT ELASTIC** if further movement is suspected.
4. Mix **MAXGRIP** powder to a pourable consistency according to product specifications. Note – if working on a vertical surface mix to a trowellable mortar and trowel into channel.
5. Pour **MAXGRIP** mixture into channel.
6. Leave for 15-20 minutes to set.
7. Once **MAXGRIP** or **Maxjoint Elastic** has set coat with **MAXSEAL FLEX** according to product specification. Apply two coats to achieve complete waterproof seal.

© Scientific Waterproofing Products Pty Ltd. ABN: 155 659 948 All rights reserved.

Address: Unit 4/92 Bryant Street, Padstow, NSW 2211, AUSTRALIA

Tel: +61 2 9771 0011 Fax: +61 2 9771 0111

Email: admin@swppl.com.au

National Hotline: 1300 303 301 National Faxline: 1300 369 932

<http://swppl.com.au/>