



Specs: 26.22Specs20

TRAFFIC SURFACING and Waterproofing – Horizontal Surfaces

Products required

- **MAXSEAL SUPER/FOUNDATION**
- **MAXSEAL FLEX TRAFFIC**

Method

1. Remove all render, paint or other material from the substrate.
2. On HEBEL Board, surface to be coated must be primed first with a single coat of **MAXSEAL FOUNDATION** or **SUPER** mixed to a slurry (2 parts powder to 1 part water). This will seal the surface in preparation for finish coats. **WET** surface before applying prime coat.
3. Leave to cure overnight.
4. Apply coat **MAXSEAL TRAFFIC**
 - a. 3 to 6 hours between coats
 - b. Apply second coat
 - c. 24 to 48 hours to traffic.
5. **MAXSEAL TRAFFIC**. Remember to dampen surface prior to application of coats.
6. Leave for 24-48 hours to cure.
7. Can be applied to Hardie's Secura™ Flooring as trafficable, waterproof coating.

© Scientific Waterproofing Products Pty Ltd. ABN: 155 659 948 All rights reserved.

Address: Unit 4/92 Bryant Street, Padstow, NSW 2211, AUSTRALIA

Tel: +61 2 9771 0011 Fax: +61 2 9771 0111

Email: admin@swppl.com.au

National Hotline: 1300 303 301 National Faxline: 1300 369 932

<http://swppl.com.au/>