



Specs: 26.26Specs20

Waterproofing Rendered External Surfaces.

Note – Rendered surfaces subject to negative hydrostatic pressure must have the render removed before any repair can be affected

Products required

- **MAXPLUG**
- **MAXREST**
- **MAXSEAL FLEX – MAXSEAL FOUNDATION**

Method

EXTERNAL:

1. Ensure that all loose render and paint has been removed, replace all missing render using **MAXREST**
2. Apply: **MAXSEAL, MAXQUICK** - or
3. **MAXSEAL FLEX** where render is showing signs of shrinkage cracking or paint cannot be removed. Finish off with second coat of **MAXSEAL FLEX, or MAXQUICK.**

INTERNAL: -Rising damp or damp retaining walls.

1. Remove all render to approximately 300 – 500 mm above the water entry or dampness.
2. Apply 2 coats of **MAXSEAL FOUNDATION** and re-render.

© Scientific Waterproofing Products Pty Ltd. ABN: 155 659 948 All rights reserved.

Address: Unit 4/92 Bryant Street, Padstow, NSW 2211, AUSTRALIA

Tel: +61 2 9771 0011 Fax: +61 2 9771 0111

Email: admin@swppl.com.au

National Hotline: 1300 303 301 National Faxline: 1300 369 932

<http://swppl.com.au/>