



Specs: 26.03Specs20

Waterproofing Compressed Fibro & Blue Board

Products required

- **MAXJOINT ELASTIC**
- **MAXSEAL FLEX**
- **MAXMESH**

Method

1. Prepare area to be treated by removing any loose materials ensuring a clean and sound surface. If surface previously painted all paint must be removed.
2. Joints between sheets must be filled with **MAXJOINT ELASTIC** Coat entire surface with **MAXSEAL FLEX**, according to product specifications.
3. The **MAXSEAL FLEX** coating should be reinforced with **MAXMESH** on all joints. **MAXMESH** is a fibreglass mesh that will strengthen and reinforce the **MAXSEAL FLEX**. **MAXMESH** is incorporated into the first coat of **MAXSEAL FLEX**.
4. Leave overnight between coats.
5. Apply second coat of **MAXSEAL FLEX**, according to product specifications.
6. Leave for 3-5 days prior to applying finish coat.




Figure: Shows the **MAXJOINT ELASTIC** to fill void between sheets. The **MAXSEAL FLEX** coating with **MAXMESH** reinforcing over the joint area.



© Scientific Waterproofing Products Pty Ltd. ABN: 155 659 948 All rights reserved.

Address: Unit 4/92 Bryant Street, Padstow, NSW 2211, AUSTRALIA

Tel: +61 2 9771 0011 Fax: +61 2 9771 0111

Email: admin@swppl.com.au

National Hotline: 1300 303 301 National Faxline: 1300 369 932

<http://www.swppl.com.au/>