



Specs: 26.08Specs20

Waterproofing – Horizontal Hebel Surfaces

Products required

- **MAXSEAL SUPER/FOUNDATION**
- **MAXSEAL FLEX**
- **MAXSEAL TRAFFIC**

Method

1. Remove all render, paint or other material from the substrate.
2. Surface to be coated must be primed first with a coat of **MAXSEAL FOUNDATION** mixed to a slurry (2 parts powder to 1 part water). This will seal the surface in preparation for finish coats. Surface must be wet before applying prime coat.
3. Leave to cure overnight.
4. Final coat **MAXSEAL FLEX**
 - a. For Hebel flooring systems use **MAXSEAL FLEX**. Apply one coat over the Maxseal Foundation mixed to the ratio as indicated on the ackaging.
5. Remember to leave overnight between coats of **MAXSEAL** and **MAXSEAL FLEX**. Also remember to dampen surface prior to application of coats.
6. Leave for 4-5 days to cure.
7. After this time the surface can be tiled, rendered or painted as required.

FOR TRAFFICABLE SURFACES:

Apply 2 coats of MAXSEAL TRAFFIC after steps 1 to 3 above.

© Scientific Waterproofing Products Pty Ltd. ABN: 155 659 948 All rights reserved.

Address: Unit 4/92 Bryant Street, Padstow, NSW 2211, AUSTRALIA

Tel: +61 2 9771 0011 Fax: +61 2 9771 0111

Email: admin@swppl.com.au

National Hotline: 1300 303 301 National Faxline: 1300 369 932

<http://swppl.com.au/>