



# Specs: 26.10Specs20

## Waterproofing – Vertical Hebel Surfaces

### Products required

- **MAXSEAL FLEX OR**
- **SEALTIGHT**

### Method – DRIZORO PRODUCTS

1. Remove all render, paint or other material from the substrate.
2. Surface to be coated must be wet before applying first coat of MAXSEALFLEX.
3. Leave to cure overnight. Surface to be coated must be wet before applying second coat.
4. Remember to leave overnight between coats of **MAXSEAL FLEX**. Also remember to dampen surface prior to application of coats.
5. Leave for 4-5 days to cure.
6. After this time the surface can be tiled, rendered or painted as required.

### Method – Clear SEALTIGHT PRODUCT (not recommended for negative pressure situations or permanent contact with water)

1. Surface must **be clean and dry** before applying SEALTIGHT
2. Cannot be applied to previously coated surfaces
3. Apply to saturation using backpack or pump up spray (low pressure) until saturated.
4. Allow to stand for 20 min. re-apply until does not absorb.
5. Leave for 4-5 days to cure.
6. After this time the surface can be tiled, rendered or painted as required.

### **Will NOT seal against permanent water contact**

© Scientific Waterproofing Products Pty Ltd. ABN: 155 659 948 All rights reserved.

Address: Unit 4/92 Bryant Street, Padstow, NSW 2211, AUSTRALIA

Tel: +61 2 9771 0011 Fax: +61 2 9771 0111

Email: [admin@swppl.com.au](mailto:admin@swppl.com.au)

National Hotline: 1300 303 301 National Faxline: 1300 369 932

<http://swppl.com.au/>