



Specs: 26.24Specs20

Prevent the transmission of Moisture along Hairline Cracks.

Products required

- **MAXPLUG**
- **MAXSEALFLEX**

Method

1. Identify the hairline crack. Follow to the end of the crack and mark where it appears to end.
2. At the point where the crack appears to end drill a hole in the concrete minimum 25mm diameter to a depth of at least 50mm.
3. Use **MAXPLUG** to fill the newly drilled hole.
4. Once set the **MAXPLUG** will prevent the transmission of moisture along the crack beyond that point.
5. Coat the surface with **MAXSEAL FLEX** as required.





Figure 1 – (above) A hairline crack in a sample piece of concrete.

Figure 2 – (below) The ends of the crack have been drilled out and filled with **MAXPLUG**. The surface can now be coated.



© Scientific Waterproofing Products Pty Ltd. ABN: 155 659 948 All rights reserved.

Address: Unit4/92 Bryant Street, Padstow, NSW 2211, AUSTRALIA

Tel: +61 2 9771 0011 Fax: +61 2 9771 0111

Email: admin@swppl.com.au

National Hotline: 1300 303 301 National Faxline: 1300 369 932

<http://swppl.com.au/>